

OPERATING INSTRUCTIONS

The default operation mode of the ALLGIG-FT RER & REW is to allow "Video in motion" and navigation entry while the vehicle is in motion, A/V Input and Bluetooth phone enable. These features can be added to, or removed, with a PC via our USB interface and software, available for download at;

www.nav.tv

You will now be able to view TV/DVD in motion as well as enter navigation destinations on the move, add an A/V input and Connect a Bluetooth enabled Phone to the MYGIG radio.

The Switchable extras are;

- *A/V output,
- *Reverse Camera input,
- *Voice Recognition.

Note,

The Video Out on the AV harness will only display the image from the built-in DVD player. The camera and A/V inputs will not display through the Video Out, and the internal DVD will pause when A/V is selected.

If the vehicle did not have a backup camera option, it will now be enabled from the MENU --> System Setup -> Camera Setup screen.



NAV TV (Europe) LTD

Distribution Centre
Unit 21B Vale Business Park
Llandow, Vale of Glamorgan
CF71 7PF

Telephone: + 44 (0)8445 783 783
Fax: + 44 (0)1446 77 22 47
technical@nav.tv



ALLGIG-FT RER & REW

VIDEO & NAVIGATION IN MOTION

A/V INPUT

BLUETOOTH PHONE ENABLE

CHRYSLER 300C / SEBRING

CHRYSLER AVENGER / ASPEN

DODGE CHARGER / DAKOTA

DODGE DURANGO

JEEP GRAND CHEROKEE

JEEP COMMANDER

NAV TV (Europe) LTD

LOCATION & REMOVAL

Example GRAND CHEROKEE

1. Gently pry off the chrome bezel from the shifter trim.
2. Pry off shifter trim panel.
3. Remove 1 screw in the small compartment between the 2 power jacks on the lower console.
4. Starting from the bottom, gently pry off the centre of the dash (including climate controls and 2 vents on either side of radio).
5. Unplug all connectors and cables from the climate controls and power jacks.
6. Remove 4 screws securing the radio, pull the radio and unplug all radio connectors.



LOCATION & REMOVAL

Example CHRYSLER 300C

1. Starting from the bottom compartment, gently pry off the chrome centre dash trim (including climate controls, clock and 2 vents) by pulling away from the dash.

Note: There is no need to unplug the clock. Once the connectors to the climate controls are unplugged at the bottom, the entire unit can be swung up and out of the way.

2. Remove 4 screws securing the radio, pull the radio and unplug all radio connectors.



INSTALLATION

Connect the supplied A/V & CAMERA plug to socket 1 on the radio

Connect the supplied microphone plug to socket 2 on the radio.

Connect the supplied harness to socket 3 on the radio, to the factory harness plug and to the ALLGIG-FT interface.

