

# OPERATING INSTRUCTIONS

After choosing an artist you will then be given the list of tracks by the chosen artist, again use the larger round button to scroll, highlight and select.

FIG 4



This procedure will be identical for any of the artists, albums, playlists etc fields chosen.

After choosing a track to play next, when you are ready for that track to start you will need to press the top right hand button on the control buttons (circled in FIG1 & marked on screen as Changer in all FIG) you will then be shown the previous main menu screen with the option **CD1—Play selection** (see FIG 2) highlight and select this using the larger round button for the track to begin.

When returning to a track from “cold start” (after the car has been switched off during playback) the track will be automatically paused and the screen will display shown icon

FIG 5



To resume playback “double press” the smaller round volume button (circled in FIG 1) The icon should disappear and the track will resume.



## AUD-iPod

iPod INPUT

AUDI A6 / A8 / Q7 MMI

NAV TV (Europe) LTD



### NAV TV (Europe) LTD

Distribution Centre  
Unit 21B Vale Business Park  
Llandow, Vale of Glamorgan  
CF71 7PF

Telephone: + 44 (0)8445 783 783  
Fax: + 44 (0)1446 77 22 47  
technical@nav.tv

#### Disclaimer

NAV TV (Europe) Ltd is not liable for any incidental, consequential or indirect damages. In case of erratic behavior of the vehicle's electrical system please disconnect the NAV TV product and contact our technical support Team. NAV TV (Europe) Ltd does not assume liability for any diagnostic fees.

e11\*72/245\*95/54\*3583\*00  
RoHS 2002/95/EC—2002/96/EC

## LOCATION & REMOVAL

Installation is made at the CD Changer/CD Player unit located in the centre of the dash

The CD changer/CD Player unit is removed with AUDI removal keys only.



The Vehicle sees the AUD-IPOD as a CD Changer.

If the car is fitted with a *CD Player* then you may leave it connected and create an additional plug with the fibre optic cable supplied. If the car is equipped with a *CD Changer*, then the CD Changer will have to be fully disconnected from the car.

## INSTALLATION

### Power and other connections

Power connections can be made at the existing CD Changer unit plug.



RED/WHITE = 12v+ Permanent

BROWN = 12v- Ground

Connect the YELLOW cable on the harness supplied to the RED/WHITE or any 12v+ permanent

Connect the BLACK cable on the harness supplied to the BROWN or any 12v- Ground.

The Optical plug from the CD Changer will plug directly into the AUD-iPod interface



Plug in and route the iPod cable to desired location.

## OPERATING INSTRUCTIONS

To select iPod press the MEDIA button



You will then have the artists albums playlist etc screen displayed. Use the centre larger round button to highlight your request and press to select

FIG 2



If you have selected ARTISTS for example you will then be shown the ARTISTS list, again use the larger round button to scroll, highlight and select.

FIG 3

