

OPERATING INSTRUCTIONS

The video input is auto video sensing, when your additional source is switched on the picture will override the navigation map picture. It will revert back to the navigation picture when your source is switched off.

The second input (Camera Input) is activated when the Blue cable is made live (adding a 12v+ supply) This input will override the additional source or the navigation map when activated.



NAV TV (Europe) LTD

Distribution Centre
Unit 21B Vale Business Park
Llandow, Vale of Glamorgan
CF71 7PF

Telephone: + 44 (0)8445 783 783
Fax: + 44 (0)1446 77 22 47
technical@nav.tv

Disclaimer
NAV TV (Europe) Ltd is not liable for any incidental, consequential or indirect damages. In case of erratic behavior of the vehicle's electrical system please disconnect the NAV TV product and contact our technical support Team. NAV TV (Europe) Ltd does not assume liability for any diagnostic fees.



NAV-INHON

VIDEO INPUT
HONDA ACCORD / LEGEND
Without TV Tuner
NAV TV (Europe) LTD

e11*72/245*95/54*3583*00
RoHS 2002/95/EC—2002/96/EC

LOCATION & REMOVAL

Ensure the vehicle is equipped with Navigation

All the plugs for can be accessed at the Navigation screen which is located in dash, or at navigation computer



INSTALLATION

All the wires can be accessed at the rear of the Screen unit. The wires are in the 20 way plug

NAV- INHON Vehicle Navigation

DVD ROM 06

RED White (pin 20)
 GREEN Red (pin 19)
 BLUE Yellow (pin 10)
 YELLOW Black (pin 9)

CD ROM <06

RED pin 13
 GREEN pin 12
 BLUE pin 3
 YELLOW pin 2

Rear of supplied plug

NAV (Input)
 SCREEN (Out)

16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

20 WAY PLUG AT REAR OF SCREEN



INSTALLATION

Other connections

YELLOW to 12v+ ignition / acc

BLACK to 12v- ground

RED to 12v+ to activate video input (also auto switching)

BLUE to 12v+ to activate camera input (002)

