



NAV-INLEX

VIDEO INPUT
ALL LEXUS (separate navi)



LOCATION & REMOVAL

Ensure the vehicle is equipped with Navigation

All the plugs can be accessed at the Navigation computer which is located in the boot of most models



INSTALLATION

The following plugs are to be used

Locate the smaller white plug at the Navigation unit, remove it from the unit and insert it into the supplied harness.

Insert the supplied harness into the navigation unit, plug in and mount the interface and carry out other connections;

Other Connections

Black 12V +	to 12v+ ignition / acc
BLACK (Ground)	to 12v- ground
BLUE	to 12v+ to activate VIDEO 2
ORANGE	Cut and add switch for VIDEO 1

The RGB switch should be set to RGBS



Note:

You can also pick up the power supplies at the navigation see below:

12v	-	heavy blue
Ground	-	heavy green
IGN	-	Light pink

You will have to use a relay as the IGN is low current.

OPERATING INSTRUCTIONS

VIDEO2 (Camera Input) is activated when the Blue cable is made live (adding a 12v+ supply) This input will override the additional source (VIDEO1) or the navigation map when activated.

If VIDEO 1 is required you will need to CUT the ORANGE cable on the harness and add in an external switch. When the orange cable is broken the VIDEO 1 source will be activated. When re-connected the factory Navigation will be restored.

