

OPERATING INSTRUCTIONS

The A/V input you have added can be viewed via the TV button.

If you have installed the NAVTV “video in motion” interface with an external switch to activate and deactivate the feature the switch should be in the on position for the added A/V input to be viewed whilst in motion.

If you have not chosen to use an external switch the “video in motion” feature will be permanently active.



NAV TV (Europe) LTD

Distribution Centre
Unit 21B Vale Business Park
Llandow, Vale of Glamorgan
CF71 7PF

Telephone: + 44 (0)8445 783 783
Fax: + 44 (0)1446 77 22 47
technical@nav.tv

Disclaimer
NAV TV (Europe) Ltd is not liable for any incidental, consequential or indirect damages. In case of erratic behavior of the vehicle's electrical system please disconnect the NAV TV product and contact our technical support Team. NAV TV (Europe) Ltd does not assume liability for any diagnostic fees.



NAV-INBENPH

A/V INPUT & VIDEO IN MOTION
BENTLEY / PHAETON
Without TV Tuner

NAV TV (Europe) LTD

e11*72/245*95/54*3583*00
e11*72/245*2004/104*4020*00
RoHS 2002/95/EC—2002/96/EC

LOCATION & REMOVAL

Installation is made at the front unit for both “video in motion” and A/V input parts.

To remove the unit you will need to first remove the speaker grille at the top of the dash (trim clips) next from the top pull the wood trim surrounding the unit, the leather dash is easily marked. You should now see 5 screws (2 either side and 1 bot-tom-centre) holding the unit.

The front unit will need to be removed and disconnected from the car, the connections you need are found at the POWER ISO and GREEN 32 pin connector shown in the diagram below;



INSTALLATION

Video In Motion and A/V input

1. Locate the GREEN 32pin socket on the back of the unit, if it has a green plug in then remove it and insert it into the female BLACK 32 pin socket on the supplied NAVTV harness,
2. Insert the supplied NAVTV 32 pin BLACK plug into the GREEN socket on the Head Unit, (see location and removal fig)
3. Connect the RED & PURPLE cable to 12v+ perm
4. Connect the BLACK cable to 12v- ground
5. Insert the interfaces to the fitted loom as labelled, see diagram opposite
6. Connect your Video lead to the socket on the Interface labelled (VIDEO)
7. Connect your Audio leads to the RED/BLACK cable sockets,

You may wish to cut the purple cable (pin 5) of the VIMCANBENPH and install a external switch to activate and de-activate the Video in motion feature (Do not use 12v+ accessory or ignition)

INSTALLATION

